

## Packet Tracer - Subnet an IPv4 Network

Name: Jhury Kevin P. Lastre

**Date:** 10/22/2022

## **General Instruction**

Place your answers (in **bold red**) inside the box provided or on the table on each question.

## **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
CustomerRouter	G0/0	192.16.0.1	255.255.255.192	N/A
	G0/1	192.168.0.65	255.255.255.192	
	S0/1/0	209.165.201.2	255.255.255.252	
LAN-A Switch	VLAN1	192.168.0.2	255.255.255.192	192.168.0.1
LAN-B Switch	VLAN1	192.168.0.66	255.255.255.192	192.168.0.65
PC-A	NIC	192.168.0.62	255.255.255.192	192.168.0.1
РС-В	NIC	192.168.0.126	255.255.255.192	192.168.0.65
ISPRouter	G0/0	209.165.200.225	255.255.255.224	N/A
	S0/1/0	209.165.201.1	255.255.255.252	
ISPSwitch	VLAN1	209.165.200.226	255.255.255.224	209.165.200.225
ISP Workstation	NIC	209.165.200.235	255.255.255.224	209.165.200.225
ISP Server	NIC	209.165.200.240	255.255.255.224	209.165.200.225

## **Objectives**

Part 1: Design an IPv4 Network Subnetting Scheme

Part 2: Configure the Devices

Part 3: Test and Troubleshoot the Network

## **Background / Scenario**

In this activity, you will subnet the Customer network into multiple subnets. The subnet scheme should be based on the number of host computers required in each subnet, as well as other network considerations, like future network host expansion.

After you have created a subnetting scheme and completed the table by filling in the missing host and interface IP addresses, you will configure the host PCs, switches and router interfaces.

After the network devices and host PCs have been configured, you will use the **ping** command to test for network connectivity.

#### Instructions

## Part 1: Subnet the Assigned Network

# Step 1: Create a subnetting scheme that meets the required number of subnets and required number of host addresses.

In this scenario, you are a network technician assigned to install a new network for a customer. You must create multiple subnets out of the 192.168.0.0/24 network address space to meet the following requirements:

- a. The first subnet is the LAN-A network. You need a minimum of 50 host IP addresses.
- b. The second subnet is the LAN-B network. You need a minimum of 40 host IP addresses.
- c. You also need at least two additional unused subnets for future network expansion.

**Note**: Variable length subnet masks will not be used. All of the device subnet masks should be the same length.

d. Answer the following questions to help create a subnetting scheme that meets the stated network requirements:

How many host addresses are needed in the largest required subnet?

50

What is the minimum number of subnets required?

4 networks

The network that you are tasked to subnet is 192.168.0.0/24. What is the /24 subnet mask in binary?

1111111.11111111.11111111.00000000

e. The subnet mask is made up of two portions, the network portion, and the host portion. This is represented in the binary by the ones and the zeros in the subnet mask.

In the network mask, what do the ones represent?

**Network portion** 

In the network mask, what do the zeros represent?

**Host portion** 

f. To subnet a network, bits from the host portion of the original network mask are changed into subnet bits. The number of subnet bits defines the number of subnets. Given each of the possible subnet masks depicted in the following binary format, how many subnets and how many hosts are created in each example?

**Hint**: Remember that the number of host bits (to the power of 2) defines the number of hosts per subnet (minus 2), and the number of subnet bits (to the power of two) defines the number of subnets. The subnet bits (shown in bold) are the bits that have been borrowed beyond the original network mask of /24. The /24 is the prefix notation and corresponds to a dotted decimal mask of 255.255.255.0.

1) (/25) 11111111.11111111.1111111.**1**0000000

Dotted decimal subnet mask equivalent:

255.255.255.128

Number of subnets? Number of hosts?

2 subnets, 128 hosts - 2 = 126 hosts per subnet

Dotted decimal subnet mask equivalent:

255.255.255.192

Number of subnets? Number of hosts?

4 subnets, 64 hosts - 2 = 62 hosts per subnet

3) (/27) 111111111.11111111.11111111.**111**00000

Dotted decimal subnet mask equivalent:

255.255.255.224

Number of subnets? Number of hosts?

8 subnets and 32 hosts - 2 = 30 hosts per subnet

Dotted decimal subnet mask equivalent:

255.255.255.240

Number of subnets? Number of hosts?

16 subnets, 16 hosts – 2 = 14 hosts per subnet

Dotted decimal subnet mask equivalent:

255.255.255.248

Number of subnets? Number of hosts?

32 subnets and 8 hosts -2 = 6 hosts per subnet

Dotted decimal subnet mask equivalent:

255.255.255.252

Number of subnets? Number of hosts?

64 subnets and 4 hosts - 2 = 2 hosts per subnet

Considering your answers above, which subnet masks meet the required number of minimum host addresses?

/25, /26

Considering your answers above, which subnet masks meets the minimum number of subnets required?

/26, /27, /28, /29, /30

Considering your answers above, which subnet mask meets both the required minimum number of hosts and the minimum number of subnets required?

/26 will give you the four subnets that are required, and 62 hosts per subnet

When you have determined which subnet mask meets all of the stated network requirements, derive each of the subnets. List the subnets from first to last in the table. Remember that the first subnet is 192.168.0.0 with the chosen subnet mask.

Subnet Address	Prefix	Subnet Mask
192.168.0.0	/26	255.255.255.192
192.168.0.64	/26	255.255.255.192
192.168.0.128	/26	255.255.255.192
192.168.0.192	/26	255.255.255.192

#### Step 2: Fill in the missing IP addresses in the Addressing Table

Assign IP addresses based on the following criteria: Use the ISP Network settings as an example.

- a. Assign the first subnet to LAN-A.
  - 1) Use the first host address for the CustomerRouter interface connected to LAN-A switch.
  - Use the second host address for the LAN-A switch. Make sure to assign a default gateway address for the switch.
  - Use the last host address for PC-A. Make sure to assign a default gateway address for the PC.
- b. Assign the second subnet to LAN-B.
  - 1) Use the first host address for the CustomerRouter interface connected to LAN-B switch.
  - 2) Use the second host address for the LAN-B switch. Make sure to assign a default gateway address for the switch.
  - 3) Use the last host address for PC-B. Make sure to assign a default gateway address for the PC.

## Part 2: Configure the Devices

Configure basic settings on the PCs, switches, and router. Refer to the Addressing Table for device names and address information.

## Step 1: Configure CustomerRouter.

- a. Set the enable secret password on CustomerRouter to Class123
- b. Set the console login password to Cisco123.
- c. Configure CustomerRouter as the hostname for the router.
- d. Configure the G0/0 and G0/1 interfaces with IP addresses and subnet masks, and then enable them.
- e. Save the running configuration to the startup configuration file.

#### Step 2: Configure the two customer LAN switches.

Configure the IP addresses on interface VLAN 1 on the two customer LAN switches. Make sure to configure the correct default gateway on each switch.

#### Step 3: Configure the PC interfaces.

Configure the IP address, subnet mask, and default gateway settings on PC-A and PC-B.

## Part 3: Test and Troubleshoot the Network

In Part 3, you will use the ping command to test network connectivity.

a. Determine if PC-A can communicate with its default gateway. Do you get a reply?

Yes

b. Determine if PC-B can communicate with its default gateway. Do you get a reply?

Yes

c. Determine if PC-A can communicate with PC-B. Do you get a reply?

Yes

If you answered "no" to any of the preceding questions, then you should go back and check your IP address and subnet mask configurations, and ensure that the default gateways have been correctly configured on PC-A and PC-B.

## Part 4: Post your screenshots

On the PT Activity window, make sure that the completion grade is **100%**. Click on the **Check Results** button and select the **Assessment Items** tab. Take a screen shot of the whole window, showing the table of assessment items, and the score/item count. Own your photo by placing a watermark on your photo with your name and USC ID Number. Paste your screenshot below:

